CONTROL AT YOUR FINGERTIPS

PRODUCT DESCRIPTION

Suggestion for Maximum Door Thickness(Latch Part Exposed)

PRODUCT SPECIFICATIONS

- Size: 11.8 x 2.8 x 1.1 inches
- Door thickness: 1.38 to 2.36 inches
- Smart type: Anti-security level: Grade 2
- Mechanical key: Anti-security level: Grade 2
- Operating temperature: -4°F to 140°F
- Operating humidity: 20% to 90% RH (non-condensing)
- Door opening methods: PIN code, Door fingerprint, (accessory) Bluetooth, Mechanical key, Emergency charging
- Fingerprint sensor type: FPC semiconductor fingerprint sensor
- Fingerprint recognition time: Less than 0.5 second (average)
- Ignorant users: with a total capacity of 200 groups
- Fingerprint capacity: 200
- Errors: Over 10 attempts
- Static power consumption: Less than 400 microamperes
- Low battery alarm: 4.8V±0.2V
- Battery: 4 pieces of AA alkaline batteries
- Emergency backup life: 500 times

ACCESSORY LIST

- Select accessories of different specifications according to the thickness of the door.
- Mechanical key: Please keep the mechanical key properly. In case of dead battery or malfunction of the electronic lock, mechanical key can be used to open the door.

DOOR OPENING DIRECTIONS

DOOR DRILLING DIAGRAM

LOCK BODY REVERSAL SCHEMATIC DIAGRAM

1. Loosen the screws shown in the diagram.
2. Remove the battery cover before adjusting the . So that the latch is easier to be pushed out.
3. Rotate the latch tongue by 90°, and then tighten the screws. Reinstall the battery cover.

For wooden doors, use a square nut to push out the main lock tongue and the top and bottom hooks. Use a flat-head screwdriver to push out the latch tongue. Rotate the latch tongue by 180 degrees, and then push it back in. Ensure that the latch tongue is pushed out and retracted smoothly.

INSTALL THE LOCK BODY

INSTALL THE AUTOMATIC LOCK HEAD

INSTALLATION OF FRONT PANEL ACCESSORIES

INSTALL THE FRONT PANEL

INSTALLATION OF THE REAR PANEL, BATTERY, AND BATTERY COMPARTMENT COVER

1. Pull out the cable from the hole, and connect the cable to the rear panel.
2. Put the cable into the cable channel, and then put the rear panel on the door.
3. Put in the screws with Insert the end of the square shaft that is similar to the shape of the screw hole into the screw hole, and then rotate the shaft to tighten the screws.
4. Put in the batteries, and then put on the battery cover. Please pay attention to the battery polarity, and then tighten the battery cover screw.Remove the fix screw from the battery cover.
5. Press inward the battery cover and then remove the battery cover.

Rear Panel
Rear Panel
Square Shaft
Square Shaft
Screw Hole
Screw Hole
Battery Cover
Battery Cover
Battery Holder
Battery Holder
Display Screen
Display Screen
Install the cable and the rear panel on the door, and then put the cable in the cable channel. Make sure the cable is not pressed by the screws when you tighten the screws. Install the front panel at last.
Install the cable and the rear panel on the door, and then put the cable in the cable channel. Make sure the cable is not pressed by the screws when you tighten the screws. Install the front panel at last.
Main Screws
Main Screws
Main Screws