ACCESS MADE EFFORTLESS



PRODUCT DESCRIPTION

Front Panel (Outdoor)
Back Panel (Outdoor)
Fingerprint Sensor
Keypad
Camera
Card Reader
Speaker
Mic
Tamper Switch
Lock Hook
Lock Tongue
Lock Body
Lock Head
Lock Head Cover
Lock Head Cover Fixing Screw
Lock Head Cover Fixing Hole
Lock Head Cover Fixing Hook
Lock Head Cover Fixing Hook Slot
Lock Head Cover Fixing Hook Slot
Lock Head Cover Fixing Hook Slot